Use of Model T135-8 and StreamLine 6

SCOPE:

This reference guide shows the suggested way to utilize the model 14374, Three section basket, in the Model T135-8 and StreamLine 6 when processing Bill Validators (Cash Boxes) in the gaming industry. Correct location of the cash boxes within the basket allows for effectively processing them to insure proper operation.

PROCEDURE:

- 1. Please refer to T-Series manual for proper use of Ultrasonic equipment.
- 2. Open access door on cash box and insert body of cash box into a basket opening
- 3. Allow door to remain in the open position by allowing it to rest on basket frame.
- 5. Repeat procedure for up to three (3) cash boxes
- 6. Situate the baskets in the T135-8 by resting the protective tipped ears on the upper lip of the tank
- 7. Process in timed ultrasonic bath filled with adequate detergent and water.
- 8. Two Model 14374 baskets will fit in the StreamLine 6, enabling the process of up to six (6) cash boxes. (see fig 3)

